

Positioning:

- On the left key block (picture) 2 cm from the cheek, parallel to cheek.
- Align centrally with the name-board, keep it and shut the fallboard for a test. If fallboard falls too fast, push the stick more to front. If fall is too slow, push it backward, if necessary the small roll can touch fallboard. Try till optimal closing speed is reached.

Fixing:



- Clean the key block, remove the adhesive protective film from the stick and press it firmly against the determined position.

Attention:

- Don't put your finger between lever arm and fallboard stop stick.
- Don't use pressure when closing the fallboard.
- Don't block the lever while opening and closing.
- When dismantling the stick don't pull the lever arm. **Risk of injury!**

The fallboard stop stick has been designed for piano fallboards.